

# AssayMax™ Rat Transferrin ELISA Kit

Assaypro LLC 3400 Harry S Truman Blvd St. Charles, MO 63301 T (636) 447-9175 F (636) 395-7419 www.assaypro.com

For any questions regarding troubleshooting or performing the assay, please contact our support team at support@assaypro.com.

Thank you for choosing Assaypro.

## **Assay Summary**

**Step 1**. Add 25  $\mu$ l of Standard or Sample and 25  $\mu$ l of Biotinylated Protein per well. Incubate 2 hours.

**Step 2**. Wash, then add 50  $\mu$ l of SP Conjugate per well. Incubate 30 minutes.

**Step 3.** Wash, then add 50  $\mu$ l of Chromogen Substrate per well. Incubate 8 minutes.

**Step 4.** Add 50  $\mu$ l of Stop Solution per well. Read at 450 nm immediately.

# **Symbol Key**



Consult instructions for use.

# **Assay Template**

12								
11								
10								
6								
∞								
7								
9								
.c								
4								
ю								
2								
1								
	Ą	В	3	Q	3	Ŧ	9	I

# AssayMax™ Rat Transferrin ELISA Kit

Catalog No. ERT2105-1
Sample insert for reference use only

#### Introduction

Transferrin is a plasma protein that transports iron through the blood to the liver, spleen, and bone marrow. Low transferrin levels in plasma could be associated with anemia (1) and chronic liver disease (2). On the other hand, high plasma transferrin levels could indicate iron deficiency anemia (3).

#### Principle of the Assay

The AssayMax™ Rat Transferrin ELISA (Enzyme-Linked Immunosorbent Assay) Kit is designed for detection of transferrin in rat plasma and serum samples. This assay employs a quantitative competitive enzyme immunoassay technique that measures rat transferrin in less than 3 hours. A polyclonal antibody specific for rat transferrin has been pre-coated onto a 96-well microplate with removable strips. Transferrin in standards and samples is competed with a biotinylated rat transferrin protein sandwiched by the immobilized antibody and streptavidin-peroxidase (SP) conjugate. All unbound material is washed away and a peroxidase enzyme substrate is added. The color development is stopped and the intensity of the color is measured.

### **Caution and Warning**

- This product is for Research Use Only and is not intended for use in diagnostic procedures.
- Prepare all reagents (diluent buffer, wash buffer, standard, biotinylated protein, and SP conjugate), as instructed, prior to running the assay.
- Prepare all samples prior to running the assay. The dilution factors for the samples are suggested in this insert. However, the user should determine the optimal dilution factor.
- Spin down the SP conjugate vial before opening and using contents.
- The Stop Solution is an acidic solution.
- The kit should not be used beyond the expiration date.

#### Reagents

 Rat Transferrin Microplate: A 96-well polystyrene microplate (12 strips of 8 wells) coated with a polyclonal antibody against rat transferrin.

- Sealing Tapes: Each kit contains 3 precut, pressure sensitive sealing tapes that can be cut to fit the format of the individual assay.
- Rat Transferrin Standard: Rat transferrin in a buffered protein base (3 µg, lyophilized).
- Biotinylated Rat Transferrin Protein (1x): Lyophilized.
- MIX Diluent Concentrate (10x): A 10-fold concentrated buffered protein base (30 ml).
- Wash Buffer Concentrate (20x): A 20-fold concentrated buffered surfactant (30 ml).
- SP Conjugate (100x): A 100-fold concentrate (80 μl).
- Chromogen Substrate (1x): A stabilized peroxidase chromogen substrate tetramethylbenzidine (7 ml).
- **Stop Solution (1x):** A 0.5 N hydrochloric acid solution to stop the chromogen substrate reaction (11 ml).

#### **Storage Condition**

- Upon arrival, immediately store components of the kit at recommended temperatures up to the expiration date.
- Store SP Conjugate at -20°C.
- Store Microplate, Diluent Concentrate (10x), Wash Buffer, Stop Solution, and Chromogen Substrate at 2-8°C.
- Unused microplate wells may be returned to the foil pouch with the desiccant packs and resealed. May be stored for up to 30 days in a vacuum desiccator.
- Store Standard and Biotinylated Protein at 2-8°C before reconstituting with Diluent and at -20°C after reconstituting with Diluent.

## **Other Supplies Required**

- Microplate reader capable of measuring absorbance at 450 nm
- Pipettes (1-20 μl, 20-200 μl, 200-1000 μl, and multiple channel)
- Deionized or distilled reagent grade water

## Sample Collection, Preparation, and Storage

Plasma: Collect plasma using one-tenth volume of 0.1 M sodium citrate
as an anticoagulant. Centrifuge samples at 3000 x g for 10 minutes and
collect plasma. A 3000-fold sample dilution is suggested into MIX
Diluent; however, user should determine optimal dilution factor
depending on application needs. The undiluted samples can be stored at
-20°C or below for up to 3 months. Avoid repeated freeze-thaw cycles.

• **Serum:** Samples should be collected into a serum separator tube. After clot formation, centrifuge samples at 3000 x g for 10 minutes and remove serum. A 3000-fold sample dilution is suggested into MIX Diluent; however, user should determine optimal dilution factor depending on application needs. The undiluted samples can be stored at -20°C or below for up to 3 months. Avoid repeated freeze-thaw cycles.

Applicable samples may also include biofluids, cell culture, and tissue homogenates. If necessary, user should determine optimal dilution factor depending on application needs.

#### Refer to Dilution Guidelines for further instruction.

	Guidelines for Dilutions of 100-fold or Greater				
	(for reference only; please follow the insert for specific dilution suggested)				
100x			10000x		
A)	4 μl sample: 396 μl buffer (100x) = 100-fold dilution  Assuming the needed volume is less than or equal to 400 μl.	A) B)	4 μl sample : 396 μl buffer (100x) 4 μl of A : 396 μl buffer (100x) = 10000-fold dilution Assuming the needed volume is less than		
1000x			or equal to 400 μl. <b>100000x</b>		
A)	4 μl sample : 396 μl buffer (100x)	A)	4 μl sample : 396 μl buffer (100x)		
B)	24 μl of A : 216 μl buffer (10x)	B)	4 μl of A : 396 μl buffer (100x)		
	= 1000-fold dilution	C)	24 μl of B : 216 μl buffer (10x) = 100000-fold dilution		
	Assuming the needed volume is less than or equal to 240 $\mu$ l.		Assuming the needed volume is less than or equal to 240 $\mu$ l.		

#### Reagent Preparation

- Freshly dilute all reagents and bring all reagents to room temperature before use.
- MIX Diluent Concentrate (10x): Dilute the MIX Diluent Concentrate 10fold with reagent grade water to produce a 1x solution. When diluting
  the concentrate, make sure to rinse the bottle thoroughly to extract any
  precipitates left in the bottle. Mix the 1x solution gently until the crystals
  have completely dissolved. Store for up to 30 days at 2-8°C.
- Rat Transferrin Standard: Reconstitute the Rat Transferrin Standard (3 μg) with 0.6 ml of MIX Diluent to generate a 5 μg/ml standard stock solution. Allow the vial to sit for 10 minutes with gentle agitation prior to making dilutions. Prepare duplicate or triplicate standard points by serially diluting from the standard stock solution (5 μg/ml) 2-fold with equal volume of MIX Diluent to produce 2.5, 1.25, 0.625, 0.313, and 0.156 μg/ml solutions. MIX Diluent serves as the zero standard (0 μg/ml).

Any remaining stock solution should be stored at -20°C and used within 30 days. Avoid repeated freeze-thaw cycles.

Standard Point	Dilution	[Transferrin] (µg/ml)
P1	1 part Standard (5 μg/ml)	5.0
P2	1 part P1 + 1 part MIX Diluent	2.5
P3	1 part P2 + 1 part MIX Diluent	1.25
P4	1 part P3 + 1 part MIX Diluent	0.625
P5	1 part P4 + 1 part MIX Diluent	0.313
Р6	1 part P5 + 1 part MIX Diluent	0.156
P7	MIX Diluent	0.0

- Biotinylated Rat Transferrin Protein (1x): Reconstitute the Biotinylated
  Rat Transferrin Protein with 4 ml of MIX Diluent to generate a stock
  solution. Allow the vial to sit for 10 minutes with gentle agitation prior to
  use. Any remaining stock solution should be stored at -20°C and used
  within 30 days. Avoid repeated freeze-thaw cycles.
- Wash Buffer Concentrate (20x): Dilute the Wash Buffer Concentrate 20fold with reagent grade water to produce a 1x solution. When diluting
  the concentrate, make sure to rinse the bottle thoroughly to extract any
  precipitates left in the bottle. Mix the 1x solution gently until the crystals
  have completely dissolved.
- SP Conjugate (100x): Spin down the SP Conjugate briefly and dilute the desired amount of the conjugate 100-fold with MIX Diluent to produce a 1x solution. The undiluted conjugate should be stored at -20°C.

## **Assay Procedure**

- Prepare all reagents, standard solutions, and samples as instructed. Bring all reagents to room temperature before use. The assay is performed at room temperature (20-25°C).
- Remove excess microplate strips from the plate frame and return them immediately to the foil pouch with desiccants inside. Reseal the pouch securely to minimize exposure to water vapor and store in a vacuum desiccator.
- Add 25 μl of Rat Transferrin Standard or sample to each well, and immediately add 25 μl of Biotinylated Rat Transferrin Protein to each well (on top of the standard or sample). Gently tap plate to ensure thorough mixing. Break any bubbles that may have formed. Cover wells with a sealing tape and incubate for 2 hours. Start the timer after the last addition.
- Wash the microplate manually or automatically using a microplate washer. Invert the plate and decant the contents; hit 4-5 times on

- absorbent material to completely remove the liquid. If washing manually, wash five times with 200  $\mu$ l of Wash Buffer per well. Invert the plate each time and decant the contents; hit 4-5 times on absorbent material to completely remove the liquid. If using a microplate washer, wash six times with 300  $\mu$ l of Wash Buffer per well; invert the plate and hit 4-5 times on absorbent material to completely remove the liquid.
- Add 50 µl of SP Conjugate to each well. Gently tap plate to thoroughly coat the wells. Break any bubbles that may have formed. Cover wells with a sealing tape and incubate for 30 minutes. Turn on the microplate reader and set up the program in advance.
- Wash the microplate as described above.
- Add 50 µl of Chromogen Substrate to each well. Gently tap plate to thoroughly coat the wells. Break any bubbles that may have formed. Incubate in ambient light for 8 minutes or until the optimal blue color density develops.
- Add 50 µl of Stop Solution to each well. The color will change from blue to yellow. Gently tap plate to ensure thorough mixing. Break any bubbles that may have formed.
- Read the absorbance on a microplate reader at a wavelength of 450 nm immediately. If wavelength correction is available, subtract readings at 570 nm from those at 450 nm to correct optical imperfections.
   Otherwise, read the plate at 450 nm only. Please note that some unstable black particles may be generated at low concentration points after stopping the reaction for about 10 minutes, which will reduce the readings.

## **Data Analysis**

- Calculate the mean value of the duplicate or triplicate readings for each standard and sample.
- To generate a standard curve, plot the graph using the standard concentrations on the x-axis and the corresponding mean 450 nm absorbance (OD) on the y-axis. The best fit line can be determined by regression analysis using log-log or four-parameter logistic curve fit.
- Determine the unknown sample concentration from the Standard Curve and multiply the value by the dilution factor.

## **Typical Data**


The typical data is provided for reference only. Individual laboratory
means may vary from the values listed. Variations between laboratories
may be caused by technique differences.

Standard Point	μg/ml	OD	Average OD
P1	5.0	0.137	0.133
LI	3.0	0.129	0.133
P2	2.5	0.262	0.269
ΓZ	2.5	0.276	0.203
P3	1.25	0.586	0.573
гэ	1.23	0.560	0.575
P4	0.625	1.028	1.048
F <del>4</del>	1.068	1.068	1.040
P5	0.313	1.422	1.451
FJ	0.515	1.480	1.431
P6	0.156	1.846	1.882
FU	0.130	1.918	1.002
P7	0.0	2.302	2.254
17	0.0	2.206	2.254
Sample: Poo	oled Normal	0.628	0.645
Sodium Citrate	Plasma (3000x)	0.662	0.645
Sample: Poo	oled Normal	0.654	0.640
Serum	(3000x)	0.626	0.640

## **Standard Curve**

• The curve is provided for illustration only. A standard curve should be generated each time the assay is performed.

## Rat Transferrin Standard Curve



#### Reference Value

 Normal plasma and serum samples were tested (n=40). On average, rat transferrin level was 3305 μg/ml.

Sample	n	Average Value (μg/ml)
Pooled Normal Plasma	10	3260
Normal Plasma	20	3281
Pooled Normal Serum	10	3375

#### **Performance Characteristics**

- The minimum detectable dose of rat transferrin as calculated by 2SD from the mean of a zero standard was established to be 0.14 µg/ml.
- Intra-assay precision was determined by testing three plasma samples twenty times in one assay.
- Inter-assay precision was determined by testing three plasma samples in twenty assays.

	Intra-Assay Precision			Inter	-Assay Pred	ision
Sample	1	2	3	1	2	3
n	20	20	20	20	20	20
CV (%)	5.1%	6.0%	4.4%	10.6%	9.5%	8.7%
Average CV (%)		5.2%			9.6%	

#### Recovery

Standard Added Value	0.625 – 2.5 μg/ml
Recovery %	88 – 112%
Average Recovery %	95%

## Linearity

• Plasma and serum samples were serially diluted to test for linearity.

Average Percentage of Expected Value (%)			
Sample Dilution	Plasma	Serum	
1500x	107%	105%	
3000x	97%	98%	
6000x	91%	95%	

## **Cross-Reactivity**

Species	Cross-Reactivity (%)
Canine	None
Bovine	None
Monkey	None
Mouse	None
Human	None
Swine	None
Rabbit	None
Protein	Cross-Reactivity (%)
Apotransferrin	70%

# Troubleshooting

Issue	Causes	Course of Action
	Use of improper components	Check the expiration date listed before use.     Do not interchange components from different lots.
	Improper wash step	<ul> <li>Check that the correct wash buffer is being used.</li> <li>Check that all wells are empty after aspiration.</li> <li>Check that the microplate washer is dispensing properly.</li> <li>If washing by pipette, check for proper pipetting technique.</li> </ul>
cisior	Splashing of reagents while loading wells	Pipette properly in a controlled and careful manner.
Low Precision	Inconsistent volumes loaded into wells	<ul> <li>Pipette properly in a controlled and careful manner.</li> <li>Check pipette calibration.</li> <li>Check pipette for proper performance.</li> </ul>
	Insufficient mixing of reagent dilutions	<ul> <li>Thoroughly agitate the lyophilized components after reconstitution.</li> <li>Thoroughly mix dilutions.</li> </ul>
	Improperly sealed microplate	<ul> <li>Check the microplate pouch for proper sealing.</li> <li>Check that the microplate pouch has no punctures.</li> <li>Check that three desiccants are inside the microplate pouch prior to sealing.</li> </ul>
gnal	Microplate was left unattended between steps	Each step of the procedure should be performed uninterrupted.
High Si	Omission of step Steps performed in incorrect order	Consult the provided procedure for complete list of steps.     Consult the provided procedure for the correct order.
Unexpectedly Low or High Signal Intensity	Insufficient amount of reagents added to wells	Check pipette calibration.     Check pipette for proper performance.
≩ ⊆	Wash step was skipped	Consult the provided procedure for all wash steps.
ję	Improper wash buffer	Check that the correct wash buffer is being used.
хрес	Improper reagent preparation	<ul> <li>Consult reagent preparation section for the correct dilutions of all reagents.</li> </ul>
Une	Insufficient or prolonged incubation periods	Consult the provided procedure for correct incubation time.

rd Curve Fit	Non-optimal sample dilution	Sandwich ELISA: If samples generate OD values higher than the highest standard point (P1), dilute samples further and repeat the assay. Competitive ELISA: If samples generate OD values lower than the highest standard point (P1), dilute samples further and repeat the assay.  User should determine the optimal dilution factor for samples.		
Standard	Contamination of	A new tip must be used for each addition of different		
a	reagents	samples or reagents during the assay procedure.		
St	Contents of wells	Verify that the sealing film is firmly in place before placing		
Ħ	evaporate	the assay in the incubator or at room temperature.		
Deficient		Pipette properly in a controlled and careful manner.		
ij	Improper pipetting	Check pipette calibration.		
Ď		<ul> <li>Check pipette for proper performance.</li> </ul>		
	Insufficient mixing of reagent dilutions	Thoroughly agitate the lyophilized components after reconstitution. Thoroughly mix dilutions.		

#### References

- (1) Averbukh Z et al. (2004) J Nephrol. 17(1):101-6.
- (2) Valberg LS et al. (1978) Can Med Assoc J. 119(3):229-36.
- (3) Akinkugbe FM et al. (1999) Afr J Med Med Sci. 28(1-2):25-9.

Version 1.6R1